

EN

User manual

Cooker

USER MANUAL

ZCV560M

la vita è bella
ZANUSSI
ITALIAN SINCE 1916

Contents

Safety information	2	Oven - Daily Use	6
Product description	4	Oven - Helpful hints and tips	7
Before first use	5	Oven - Care and Cleaning	11
Hob - Daily Use	5	What to do if...	13
Hob - Helpful hints and tips	6	Installation	13
Hob - Care and Cleaning	6	Environment concerns	14

Subject to change without notice

Safety information

Before the installation and use, read this manual carefully:

- For your own safety and the safety of your property
- For the protection of the environment
- For the correct operation of the appliance.

Always keep these instructions with the appliance also if you move or sell it.

The manufacturer is not responsible if incorrect installation or use results in damage.

Children and vulnerable people safety

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in safe way and understand the hazards involved. Children shall not play with the appliance.
- Keep all packaging away from children. There is the risk of suffocation or physical injury.
- Keep children and animals away from the appliance when the door is open or the appliance is in operation. There is the risk of injury or other permanent disability.
- If the appliance has Child lock or Key lock function, use it. It prevents children and animals from accidental operation of the appliance.

General safety

- Do not change the specifications of this appliance. There is the risk of injury and damage to the appliance.
- Do not let the appliance stay unattended during operation.
- Switch off the appliance after each use.

Installation

- Only an approved technician can install and connect the appliance. Contact an approved service centre. This

is to prevent the risks of structural damage or physical injury.

- Make sure that the appliance is not damaged because of transport. Do not connect a damaged appliance. If necessary, contact the supplier.
- Remove all packaging, stickers and layers from the appliance before first use. Do not remove the rating plate. It can invalidate the guarantee.
- Fully obey the laws, ordinances, directives and standards in force in the country where you use the appliance (safety regulations, recycling regulations, electrical or gas safety rules etc.).
- Be careful when you move the appliance. The appliance is heavy. Always use safety gloves. Do not pull the appliance by the handle.
- Make sure that the appliance is disconnected from the power supply during the installation (if applicable).
- Keep the minimum distances to the other appliances and units.
- Do not put the appliance on a base.

Electrical connection

- Only an approved electrician can install and connect the appliance. Contact an approved service centre. This is to prevent the risks of structural damage or physical injury.
- The appliance must be earthed.
- Make sure that the electrical data on the rating plate agree with your domestic power supply.
- Information on the voltage is on the rating plate.
- You must have the correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the

mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.

- The shock protection parts must be fixed in such a way that they cannot be undone without tools.
- Always use a correctly installed shockproof socket.
- When you connect electrical appliances to mains sockets, do not let cables touch or come near the hot appliance door.
- Do not use multi-way plugs, connectors and extension cables. There is a risk of fire.
- Make sure not to squash or cause damage to the mains plug (if applicable) and cable behind the appliance.
- Make sure that the mains connection is accessible after the installation.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug (if applicable).
- Do not replace or change the mains cable. Contact the service centre.

Use

- Only use the appliance for domestic cooking tasks. Do not use the appliance for commercial and industrial use. This is to prevent physical injury to persons or prevent damage to property.
- Always monitor the appliance during operation.
- Always stay away from the appliance when you open the door while the appliance is in operation. Hot steam can release. There is a risk of burns.
- Do not use this appliance if it is in contact with water. Do not operate the appliance with wet hands.
- Do not use the appliance as a work surface or storage surface.
- The cooking surface of the appliance becomes hot during use. There is a risk of burns. Do not put metallic objects, for example cutlery or saucepans lids, on the surface, as they can become hot.
- The interior of the appliance becomes hot during use. There is a risk of burns. Use gloves when you insert or remove the accessories or pots.
- Open the door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air. There is the risk of fire.
- Do not let sparks or open flames come near the appliance when you open the door.
- Do not put flammable products or items that are wet with flammable products, and/or fusible objects (made

of plastic or aluminium) in, near or on the appliance. There is a risk of explosion or fire.

- Set the cooking zones to "off" after each use.
- Do not use the cooking zones with empty cookware or without cookware
- Do not let cookware boil dry. This can cause damage to the cookware and hob surface.
- If an object or cookware falls on the hob surface, the surface can be damaged.
- Do not put hot cookware near to the control panel because the heat can cause a damage to the appliance.
- Be careful when you remove or install the accessories to prevent damage to the appliance enamel.
- Cookware made of cast iron, cast aluminium or with damaged bottoms can scratch the hob surface if you move them on the surface.
- Discoloration of the enamel has no effect on the performance of the appliance.
- To prevent damage or discoloration to the enamel:
 - do not put any objects directly on the appliance floor and do not cover it with aluminium foil;
 - do not put hot water directly into the appliance;
 - do not keep moist dishes and food in the appliance after you finish the cooking.
- Do not apply pressure on the open door.
- Do not put flammable materials in the compartment below the oven. Keep there only heat-resistant accessories (if applicable).
- Do not cover oven steam outlets. They are at the rear side of the top surface (if applicable).
- If there is a crack on the surface, disconnect the power supply. There is a risk of electric shock.
- Do not put heat-conducting materials (e.g. thin metal mesh or metal-plated heat conductors) under the cookware. Excessive heat reflection can damage the cooking surface.
- Do not use the appliance during a power cut.

Care and cleaning

- Before maintenance, make sure that the appliance is cold. There is a risk of burns. There is a risk that the glass panels can break.
- Keep the appliance clean at all times. A build-up of fats or other foodstuff can result in a fire.

- Regular cleaning prevents the surface material from deteriorating.
- For your personal safety and the safety of your property, only clean the appliance with water and soap. Do not use flammable products or products that can cause corrosion.
- Do not clean the appliance with steam cleaners, high-pressure cleaners, sharp objects, abrasive cleaning agents, abrasive sponges and stain removers.
- If you use an oven spray, follow the instructions from the manufacturer. Do not spray anything on the heating elements and the thermostat sensor (if applicable).
- Do not clean the glass door with abrasive cleaning agents or metal scraper. Heat resistant surface of the inner glass can break and shatter.
- When the door glass panels are damaged they become weak and can break. You must replace them. Contact the service centre.
- Be careful when you remove the door from the appliance. The door is heavy.
- Bulb lamps used in this appliance are special lamps selected for household appliances use only. They can-

not be used for the full or partial illumination of a household room.

- If it becomes necessary to replace the lamp use one of the same power and specifically designed for household appliances only.
- Disconnect the appliance from the power supply before the replacement of the oven lamp. There is the risk of electrical shock. Cool down the appliance. There is a risk of burns.

Service centre


- Only an approved engineer can repair or work on the appliance. Contact an approved service centre.
- Use only original spare parts.

Disposal of the appliance

- To prevent the risk of physical injury or damage:
 - Disconnect the appliance from the power supply.
 - Cut off the mains cable and discard it.
 - Discard the door catch. This prevents children or small animals from being closed inside of the appliance. There is a risk of suffocation.


Product description

General overview



- | | |
|-----------|---------------------------|
| 1 | Control panel |
| 2 | Cooking zones indicators |
| 3 | Knob for oven temperature |
| 4 | Temperature indicator |
| 5 | Hob indicator |
| 6 | Knob for oven functions |
| 7 | Knobs for the hob |
| 8 | Grill |
| 9 | Oven lamp |
| 10 | Fan |
| 11 | Rating plate |
| 12 | Shelf runner |

Cooking surface layout



- 1 Single cooking zone 1200 W
- 2 Single cooking zone 1800 W
- 3 Single cooking zone 1200 W
- 4 Residual heat indicator
- 5 Single cooking zone 1800 W

Oven accessories

- **Oven shelf**
For cookware, cake tins, roasts.
- **Flat baking tray**
For cakes and biscuits.
- **Flat aluminized baking tray**
For cakes and biscuits.

Before first use

! **Warning!** Refer to "Safety information" chapter.

i Remove all packaging, both inside and outside the oven, before using the appliance. Do not remove the rating plate.

! **Caution!** To open the oven door, always hold the handle in the centre.

Initial Cleaning

- Remove all parts from the appliance.
- Clean the appliance before first use.

! **Caution!** Do not use abrasive cleaning agents! This can damage the surface. Refer to chapter "Care and Cleaning".

Hob - Daily Use

! **Warning!** Refer to "Safety information" chapter.

• Storage compartment

Below the oven is the storage compartment. To use the compartment, lift the lower front door then pull down.

! **Warning!** The storage compartment can become hot when the appliance operates.

Preheating

1. Set function and maximum temperature.
2. Run an empty oven for 45 minutes.
3. Set function and maximum temperature.
4. Run an empty oven for 15 minutes.

This is to burn off any residue from the cavity surface. Accessories can become more hot than in normal use. During this period an odour and smoke can be emitted. This is normal. Make sure the airflow is sufficient.

Heat settings

Control knob	Function
0	Off position
1-9	Heat settings (1 = lowest heat setting; 9= highest heat setting)

1. Turn the control knob to a necessary heat setting.
The hob control indicator comes on.

Hob - Helpful hints and tips

Cookware

-  • The bottom of the cookware must be as thick and flat as possible.
- Cookware made of enamelled steel and with aluminium or copper bottoms can cause discolouration on glass ceramic surface.

Energy saving

-  • If possible, always put the lids on the cookware.

Hob - Care and Cleaning

-  **Warning!** Refer to "Safety information" chapter.

Clean the appliance after each use.

Always use cookware with clean bottom.

-  Scratches or dark stains on the glass ceramic have no effect on how the appliance operates.

To remove the dirt:

1. – **Remove immediately:** melted plastic, plastic foil, and food with sugar. If not, the dirt can cause damage to the appliance. Use a special scraper for the glass . Put the scraper on the glass surface at an acute angle and move the blade on the surface .

2. To complete the cooking process, turn the control knob to the "0" position. If all cooking zones are deactivated, the hob control indicator goes out.

Residual heat indicator

The residual heat indicator comes on when a cooking zone is hot.

 **Warning!** Risk of burns from residual heat!

- Put cookware on a cooking zone before you start it.
- Stop the cooking zones before the end of the cooking time to use residual heat.
- The bottom of pans and cooking zones must have the same dimension.

– **Remove after the appliance is sufficiently cool:** limescale rings , water rings, fat stains, shiny metallic discolorations. Use a special cleaning agent for glass ceramic or stainless steel.

2. Clean the appliance with a moist cloth and some detergent.
 3. At the end **rub the appliance dry with a clean cloth.**
- Clean the front of the appliance with a soft cloth and a solution of hot water and some detergent.
 - For metal fronts use some detergent for stainless steel.
 - Do not use scouring agents and abrasive sponges.

Oven - Daily Use

-  **Warning!** Refer to "Safety information" chapter.

Activating and deactivating the appliance

1. Turn the oven functions control knob to an oven function.

2. Turn the temperature control knob to a temperature. The temperature indicator comes on while the temperature in the appliance increases.

3. To deactivate the appliance, turn the oven functions control knob and the temperature control knob to the Off position.

safety thermostat, which interrupts the power supply. The oven switches back on again automatically, when the temperature drops.

Safety thermostat

To prevent dangerous overheating (due to incorrect use of the appliance or defective components), the oven has a

The oven functions

	Oven functions	Application
	The oven is OFF	
	Conventional cooking	Heats both from the top and bottom element. To bake and roast on one oven level.
	Full grill	The full grill element is on. To grill flat food items in large quantities. To make toasts. Maximum temperature for this function is 210 °C
	Bottom heating element	Heats only from the bottom of the oven. To bake cakes with crispy or crusty bases.
	Fan forced cooking	To roast or bake the food that requires the same cooking temperature, using more than one shelf, without flavour transference.
	Pizza economic	To roast or bake the food quickly on one level, using grill and bottom elements assisted by fan.

Oven - Helpful hints and tips

- The appliance has four shelf levels. Count the shelf levels from the bottom of the appliance floor.
- You can cook different dishes on two levels at the same time. Place the shelves on level 1 and 3.
- Moisture can condense in the appliance or on the glass doors. This is normal. Always stand back from the appliance when you open the appliance door while cooking. To decrease the condensation, run the appliance for 10 minutes before cooking.
- Wipe away moisture after every use of the appliance.
- Do not put the objects directly on the appliance floor and do not cover the components with aluminium foil when you cook. This can change the baking results and damage the enamel coating.

Baking cakes

- Preheat the oven for approximately 10 minutes before baking.

- Do not open the oven door before 3/4 of the set cooking time is up.
- If you use two baking trays at the same time, keep one level empty between them.

Cooking meat and fish

- Do not cook meat with weight below 1 kg. Cooking too small quantities makes the meat too dry.
- Use a dripping pan for very fatty food to prevent the oven from stains that can be permanent.
- Leave the meat for approximately 15 minutes before carving so that the juice does not seep out.
- To prevent too much smoke in the oven during roasting, add some water into the dripping pan. To prevent the smoke condensation, add water each time after it dries up.

Cooking times

Cooking times depend on the type of food, its consistency, and volume.

Initially, monitor the performance when you cook. Find the best settings (heat setting, cooking time, etc.) for your

cookware, recipes and quantities when you use this appliance.

Conventional cooking ☐

Food	Weight (g)	Tray type	Shelf level	Preheating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)
Pastry stripes	250	enamelled	3	-	150	25-30
Flat cake	1000	enamelled	2	10	160-170	30-35
Yeast cake with apples	2000	enamelled	3	-	170-190	40-50
Apple pie	1200+1200	2 round aluminized trays (diameter: 20 cm)	1	15	180-200	50-60
Small cakes	500	enamelled	2	10	160-180	25-30
Fatless sponge cake	350	1 round aluminized tray (diameter: 26 cm)	1	10	160-170	25-30
Drip pan cake	1500	enamelled	2	-	160-170	45-55 ¹⁾
Chicken, whole	1350	oven shelf at level 2, roasting tray at level 1	2	-	200-220	60-70
Chicken, half	1300	oven shelf at level 3, roasting tray at level 1	3	-	190-210	30-35
Pork roast cutlet	600	oven shelf at level 3, roasting tray at level 1	3	-	190-210	30-35
Flan bread	800	enamelled	2	20	230-250	10-15
Stuffed yeast cake	1200	enamelled	2	10-15	170-180	25-35
Pizza	1000	enamelled	2	10-15	200-220	30-40
Cheese cake	2600	enamelled	2	-	170-190	60-70

Food	Weight (g)	Tray type	Shelf level	Preheating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)
Swiss apple flan	1900	enamelled	1	10-15	200-220	30-40
Christmas cake	2400	enamelled	2	10-15	170-180	55-65 ²⁾
Quiche Lorraine	1000	1 round tray (diameter: 26 cm)	1	10-15	220-230	40-50
Peasant bread	750+750	2 round aluminized trays (diameter: 20 cm)	1	18 ³⁾	180-200	60-70
Romanian sponge cake	600+600	2 round aluminized trays (diameter: 25 cm)	2/2	10	160-170	40-50
Romanian sponge cake - traditional	600+600	2 round aluminized trays (diameter: 20 cm)	2/2	-	160-170	30-40
Yeast buns	800	enamelled	2	10-15	200-210	10-15
Swiss roll	500	enamelled	1	10	150-170	15-20
Meringue	400	enamelled	2	-	100-120	40-50
Crumble cake	1500	enamelled	3	10-15	180-190	25-35
Sponge cake	600	enamelled	3	10	160-170	25-35
Buttered cake	600	enamelled	2	10	180-200	20-25

1) After you switch off the appliance, leave the cake in the oven for 7 minutes.

2) After you switch off the appliance, leave the cake in the oven for 10 minutes.

3) Set the temperature to 250 °C for preheating.

Fan forced cooking

Food	Weight (g)	Tray type	Shelf level	Preheating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)
Pastry stripes	250	enamelled	3	10	140-150	20-30
Pastry stripes	250 + 250	enamelled	1/3	10	140-150	25-30
Pastry stripes	250 + 250 + 250	enamelled	1/2/3	10	150-160	30-40
Flat cake	500	enamelled	2	10	150-160	30-35

Food	Weight (g)	Tray type	Shelf level	Preheating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)
Flat cake	500 + 500	enamelled	1/3	10	150-160	35-45
Flat cake	500 + 500 + 500	enamelled	1/2/4 ¹⁾	10	155-165	40-50
Yeast cake with apples	2000	enamelled	3	-	170-180	40-50
Apple pie	1200 + 1200	2 round aluminized trays (diameter: 20 cm)	2/2	-	165-175	50-60
Small cakes	500	enamelled	2	10	150-160	20-30
Small cakes	500 + 500	enamelled	1/3	10	150-160	30-40
Small cakes	500 + 500 + 500	enamelled	1/2/4 ¹⁾	10	150-160	35-45
Fatless sponge cake	350	1 round aluminized tray (diameter: 26 cm)	1	10	150-160	20-30
Drip pan cake	1200	enamelled	2	-	150-160	30-35 ²⁾
Chicken, whole	1300	oven shelf at level 2, roasting tray at level 1	2	-	170-180	40-50
Pork roast	800	oven shelf at level 2, roasting tray at level 1	2	-	170-180	45-50
Stuffed yeast cake	1200	enamelled	2	20-30	150-160	20-30
Pizza	1000 + 1000	enamelled	1/3	-	180-200	30-40
Pizza	1000	enamelled	2	-	190-200	25-35
Cheese cake	2600	enamelled	1	-	160-170	40-50
Swiss apple flan	1900	enamelled	2	10-15	180-200	30-40
Christmas cake	2400	enamelled	2	10	150-160	35-40 ²⁾
Quiche Lorraine	1000	1 round tray (diameter: 26 cm)	2	10-15	190-210	30-40

Food	Weight (g)	Tray type	Shelf level	Preheating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)
Peasant bread	750+750	2 round aluminized trays (diameter: 20 cm)	1	15-20 ³⁾	160-170	40-50
Romanian sponge cake	600+600	2 round aluminized trays (diameter: 25 cm)	2/2	10-15	155-165	40-50
Romanian sponge cake - traditional	600+600	2 round aluminized trays (diameter: 20 cm)	2/2	-	150-160	30-40
Yeast buns	800	enamelled	3	15	180-200	10-15
Yeast buns	800 + 800	enamelled	1/3	15	180-200	15-20
Swiss roll	500	enamelled	3	10	150-160	15-25
Meringue	400	enamelled	2	-	110-120	30-40
Meringue	400 + 400	enamelled	1/3	-	110-120	45-55
Meringue	400 + 400 + 400	enamelled	1/2/4 ¹⁾	-	115-125	55-65
Crumble cake	1500	enamelled	3	-	160-170	25-35
Sponge cake	600	enamelled	2	10	150-160	25-35
Buttered cake	600 + 600	enamelled	1/3	10	160-170	25-35

1) After the cake at level 4 is done, take it out and put in the cake from level 1. Bake for ten more minutes.

2) After you switch off the appliance, leave the cake in the oven for 7 minutes.

3) Set the temperature to 250 °C for preheating.

Pizza economic

Food	Weight (g)	Shelf level	Pre-heating time (minutes)	Temperature (°C)	Cooking / baking time (minutes)	Tray type
Pizza	1000	1	-	200-210	20-30	enamelled
Pizza	1000 + 1000	1/2	-	180-200	30	level 2 enamelled, level 1 aluminized ¹⁾

1) After 20 minutes, switch the trays between the levels.

Oven - Care and Cleaning

 **Warning!** Refer to "Safety information" chapter.

- Clean the front of the appliance with a soft cloth with warm water and cleaning agent.
- To clean metal surfaces use a usual cleaning agent
- Clean the oven interior after each use. Thus you can remove dirt more easily and it does not burn on.
- Clean stubborn dirt with a special oven cleaner.
- Clean all oven accessories (with a soft cloth with warm water and cleaning agent) after each use and let them dry.
- If you have nonstick accessories, do not clean them using an aggressive agents, sharp edged objects or dishwasher. It can destroy nonstick coating!

Cleaning the oven door


The oven door has two panels of glass installed one behind the other. To make the cleaning easier remove the oven door and the internal panel of glass.

⚠ Warning! The oven door can close if you try to remove the internal panel of glass when the door is still assembled.


⚠ Warning! Make sure that the glass panels are cool, before you clean the glass door. There is risk that the glass breaks.

⚠ Warning! When the door glass panels are damaged or have scratches, the glass becomes weak and can break. To prevent this you must replace them. For more instructions, contact your local Service Centre.


Removing the oven door and the glass panel




① Open the door fully and hold the two door hinges.



② Lift and turn the levers on the two hinges.




③ Close the oven door to the first opening position (halfway). Then pull forward and remove it from its seat.




④ Place the door on a stable surface protected by a soft cloth. Use a screwdriver to remove 2 screws from bottom edge of door

Important! Do not loose the screws



⑥ Lift the inner door
⑦ Clean inner side of the door
Clean the glass panel with water and soap. Dry it carefully.




⑤ Use a spatula made of wood or plastic or equivalent to open the inner door. Hold the outer door, and push the inner door against the top edge of the door

⚠ Warning! Only clean the glass panel with water and a soap. Abrasive cleaning agents, stain removers and sharp objects (e.g. knives or scrapers) can cause damage to the glass.

Inserting the door and the glass panel

When the cleaning procedure is completed, insert the oven door. To do so, do the steps in opposite way.



Oven lamp

⚠ Warning! There is a danger of electrical shock!

Before you change the oven lamp:

- Switch off the oven.

What to do if...

Problem	Possible cause	Remedy
The residual heat indicators does not come on	The cooking zone is not hot because it operated only for a short time	If the cooking zone must be hot, speak to the after sales service
The appliance does not operate	The fuse in the fuse box is released	Control the fuse. If the fuse is released more than one time, refer to a qualified electrician.
The oven does not heat up	The oven is not switched on	Switch on the oven
The oven does not heat up	The necessary settings are not set	Control the settings
The oven lamp does not operate	The oven lamp is defective	Replace the oven lamp
Steam and condensation settle on the food and in the oven cavity	You left the dish in the oven for too long	Do not leave the dishes in the oven for longer than 15-20 minutes after the cooking process ends

If you cannot find a solution to the problem yourself, contact your dealer or the service centre.

- Remove the fuses in the fuse box or switch off the circuit breaker.

i Put a cloth on the bottom of the oven for protection of the oven light and glass cover.

Replacing the oven light bulb/cleaning the glass cover

- 1 Turn the glass cover anti-clockwise to remove it.
- 2 Clean the glass cover.
- 3 Replace the oven light bulb with applicable 300°C heat-resistant oven light bulb.
- 4 Install the glass cover.

The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of the oven cavity.

We recommend that you write the data here:

Model (MOD.)

.....

Product number (PNC)

.....

Serial number (S.N.)


.....

Installation

⚠ Warning! Refer to "Safety information" chapter.

Location of the appliance

You can install your freestanding appliance with cabinets on one or two sides and in the corner.



Minimum distances

Dimension	mm
A	690
B	150

Technical Data

Appliance class 2, sub class 1 and class 1.

Dimensions	
Height	858 mm

Environment concerns

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact

Dimensions

Width	500 mm
Depth	600 mm
Total electricity power	8685 W
Voltage	230 V
Frequency	50 Hz


Electrical installation

The manufacturer is not responsible if you do not follow safety precautions from chapter "Safety information".

This appliance is supplied without a main plug and a main cable.

Applicable cable type: H05 RR-F with adequate cross-section.

The power cable must not touch the part of the appliance shown in the illustration.



your local council, your household waste disposal service or the shop where you purchased the product.

Packaging material

The packaging material is environmentally-friendly and recyclable. Plastic parts are marked with international abbreviations such as PE, PS, etc. Dispose of the packaging material in the containers provided for this purpose at your local waste management facility.



Warning! Your appliance should be made inoperable before it is disposed of, so that it does not constitute a danger.

To do this, take the mains plug from the socket and remove the mains cable from the appliance.



www.zanussi.com/shop

CE



892944125-B-132011